



Button Cheat Sheet for Nisus

LOCK/UNLOCK FEATURE:

- 1. Press the **Up** and **Down** arrow simultaneously, this will lock and unlock the device.
- 2. The lock icon will appear closed when the device is locked.
- 3. The lock icon will appear open when the device is unlocked.



SLEEP MODE ACTIVATION:

- 1. Press the **Left** and **Right** arrow simultaneously, to activate and to deactivate.
- When sleep mode is activated, an S will appear in the bottom right side of the footer.
- 3. When sleep mode is deactivated, a S will not appear in the bottom right side of the footer.

12:42 PM July 21, 2025 Up Time: 1m Down Time: 1m mmHg Run Time: 39h:45m

RUN TIME LOCK OUT:

- 1. Press the **Left** and **Down** arrow simultaneously, to activate and to deactivate.
- 2. When run time lock out is activated, the run time font will be in blue.
- 3. When run time lock out is deactivated, the run time font will be black.



ACCESSING THE FACTORY ADMINISTRATION:

1. Press Menu button, then arrow down to Setting icon, once Setting icon is highlighted, press the Menu/Select button, scroll down to Factory Admin, press the Menu/Select button, and then enter the passcode and press the Yes button.

The password for the factory admin: Up Arrow, Down Arrow, Left Arrow, Right Arrow, **Up** Arrow, **Down** Arrow, then press the **Menu/Select** button.





